

is energized by closing the LV switch, S304. Three separate windings on transformer, T301, furnishes filament power to the tubes. The low voltage plate supply employs a type 5Z4 rectifier tube in a full wave circuit with a two section choke input filter. This supply has a total output voltage of approximately 315 volts, 240 volts is supplied to the audio amplifier, oscillator, buffer and multiplier stages. Bias voltage for the modulator and final amplifier stage is furnished by this supply. It also supplies voltage for the operation of relay, K301.

MAINTENANCE

SECTION 5

MAINTENANCE

5.1. INSPECTION.

5.1.1. GENERAL. - This radio equipment has been constructed of materials considered to be the best obtainable for the purpose and has been carefully inspected and adjusted at the factory to reduce maintenance to a minimum. However, a certain amount of checking and servicing will be necessary to maintain efficient and dependable operation. The following section has been written to aid in checking the equipment.

5.1.2. ROUTINE INSPECTION. - Routine inspection schedules should be set up for periodic checks of this equipment. This inspection should include examination of the mechanical system for excessive wear or binding and of the electrical system for electrical defects and deterioration of components.

If the routine inspection of the equipment is carried out faithfully, the chances of improper operation of the equipment are greatly minimized. It is suggested that this inspection be made as frequently as possible, and it should be sufficiently thorough to include all major electrical circuits of the equipment as well as of the mechanical portion.

a. CLEANING. - The greatest enemies of uninterrupted service in equipment of this type are corrosion and dirt. Corrosion, itself, is accelerated by the presence of dust and moisture on the component parts of the assembly. It is impossible to keep moisture out of the equipment in certain localities, but foreign particles and dust can be periodically removed by means of a soft brush and a dry, oil-free jet of air. Remove the

dust as often as a perceptible quantity accumulates in any part of the equipment. It is very important that rotating equipment, such as variable condensers and tap switches, be kept free from dust to prevent undue wear. Likewise, variable condenser plates should be kept free from dirt to avoid flashover.

One of the greatest sources of trouble in equipment located in a salty atmosphere is corrosion. Corrosion resulting from salt spray or salt-laden atmosphere may cause failure of the equipment for no apparent reason. In general, it will be found that contacts such as tap switches, tube prongs, cable plug connectors, and relay contacts are most affected by corrosion. When it is necessary to operate the equipment in localities subject to such corrosive atmosphere, inspection of wiping contacts, cable plugs, relays, etc., should be made more frequently in order to keep the equipment in good condition.

b. VACUUM TUBES. - Make a check of emission characteristics of all tubes. After making the emission check, examine the prongs on all tubes to make sure they are free from corrosion. See that all tubes are replaced correctly and fully in their sockets, and that a good electrical contact exists between the tube prong and the socket. Use caution in removing and replacing grid or plate caps on tubes so equipped. Before a tube is discarded, make certain that the tube is at fault and the trouble is not due to a loose or broken connection within the equipment. A complete set of tested tubes of the same type specified should be kept on hand at all times. If faulty operation of the transmitter is observed and tube failure suspected, each tube may be checked by replacing it with a tube known to be in good condition. Defective tubes causing an overload in power circuits may usually be located by inspection. It will be found that excessive heating or sputtering within the vacuum tubes is a good indication of a fault in the tube circuit.

If tubes have been in use for a period of time equal to or exceeding the manufacturer's tube life rating, it is suggested that they be replaced. A marked improvement in the performance of the equipment is usually noticeable after the weak tubes have been replaced.

c. PRECAUTIONS FOR SATISFACTORY TUBE LIFE.

(1) Before removing any tube from the equipment, make certain the primary power is disconnected from the equipment.

(2) Operate all tubes within $\pm 5\%$ of rated filament voltage.

(3) Do not exceed the rated plate current of any tube during normal operation of the equipment.

d. TUBE REPLACEMENT PRECAUTIONS.

(1) All tubes are removed by pulling them straight away from the chassis. Some tubes have hold-downs, be sure these are loosened before pulling on these tubes.

(2) Remove plate cap connectors from tubes with great care to prevent breaking the seal around the plate cap.

(3) Before inserting a tube make certain it is of the correct type for the socket into which it is to be placed.

NOTE

Changing master oscillator tubes (V001) may cause a slight change in master oscillator calibration.

e. TUBE TABLE.

<u>SYMBOL</u>	<u>TYPE</u>	<u>FUNCTION</u>	<u>RATED FIL. VOLTAGE</u>
V001	6SJ7	Master oscillator	6.3
V101	6AK6	Buffer amplifier	6.3
V102	6AG7	Frequency multiplier	6.3
V103	7C5	Frequency multiplier	6.3
V104	705	Frequency multiplier	6.3
V105	4D32	Power Amplifier	6.3
V201	6SL7	Audio Amplifier	6.3
V202	6SN7	Audio driver	6.3
V203	807	Modulator	6.3
V204	807	Modulator	6.3
V301	5Z4	LV Rectifier	5.0
V302	5R4GY	HV Rectifier	5.0
V303	5R4GY	HV Rectifier	5.0
V304	VR75	Bias Regulator	---
V305	0A2	Screen Voltage Limiter	---
V306	0A2	Screen Voltage Limiter	---

f. RELAYS. - All relays should be inspected at regular intervals. Check the contacts for proper alignment, pitting and corrosion. Use a burnishing tool to clean contacts - never use sandpaper or emery cloth.

5.2. TROUBLE SHOOTING.

5.2.1. GENERAL. - The most common cause of improper operation of radio equipment is tube failure. Refer to paragraph 5.1.2., b. in this section for comments concerning vacuum tube replacement. Defective tubes causing an overload in power circuits may usually be located by inspection. High voltage arcs may be caused by bent condenser plates, corrosion or dust. Corrosion resulting from operating the equipment in a salt laden atmosphere may cause failure of the equipment for no apparent reason.

In general, trouble encountered in radio apparatus can be isolated by means of various tests and measurements; then the section of the transmitter in which the trouble is located can be determined. If this is done,

the components in the associated circuit may be checked and the trouble located. Refer to the tables of meter readings and resistance measurements.

No one but an authorized and competent service man equipped with proper test facilities should be permitted to service this equipment.

5.2.2. FUSES.

a. GENERAL. - This equipment is supplied with fuses of the correct rating in each position. Defective fuses should be replaced by spares only after the circuit in question has been carefully examined to make certain that no permanent fault exists. Always replace a fuse with the rating specified by the following table.

FUSE TABLE

<u>SYMBOL</u>	<u>LOCATION</u>	<u>TYPE</u>	<u>RATING</u>
F301	LV Power supply primary	Cartridge (3AG)	3 amp.
F302	HV Power supply primary	Cartridge (3AG)	5 amp.

5.3. ALIGNMENT.

5.3.1. GENERAL. - If the exciter stages get out of alignment for any reason, it is recommended that the unit be realigned at once. Improper operation may result in damage to valuable equipment.

5.3.2. HIGH FREQUENCY OSCILLATOR. - Should trouble develop in the high frequency master oscillator, the unit should be returned to the factory for servicing. However, the unit can be serviced and realigned by persons understanding such techniques providing accurate test equipment is at hand. A crystal controlled frequency standard with outputs at 1700 and 2000 kc with an accuracy of better than .015 percent, must be used for setting the band edges.


a. PROCEDURE.

(1) Apply power to the transmitter and let the MO warm up for about 30 min. then check the oscillator frequency on a receiver. Operate the transmitter with the emission control in the CAL position and the key closed.


(2) Couple a receiver to the output of the oscillator.

(3) Set the vernier index to exact center of the dial window.

(4) Tune receiver to output of 1700 kc freq. standard.



OSCILLATOR
ADJUSTMENT



C147
⑤
①
⑤
①
⑥
③
①

④
④
④
②
⑤
C149

BOTTOM

NUMBERS REPRESENT
ORDER OF ADJUSTMENT
(SEE TEXT)

Figure 5-1 Alignment Adjustments

(5) Rotate MO to vicinity of 3400 kc on the exciter dial, and zero beat with the signal from the standard. Jot down dial reading for use as a reference.

(6) Rotate the MO dial toward 4 mc exactly 12 turns.

(7) Tune the receiver to the 2000 kc output of the standard.

(8) The MO should zero beat with the 2000 kc output of the standard at exactly 12 turns of the MO dial.

(9) If such is the case but the dial reading is incorrect, loosen the set screws in the oscillator coupler and turn the dial to the correct reading (4000 kc), after which tighten the set screws again. If the MO does not zero beat with the standard at 4 mc, proceed as follows:

(10) Read the kc difference (the difference between where the signal appeared and where it should have appeared after 12 turns) and multiply it by 5. Add this figure to the actual beat note dial setting if the beat note was less than 12 turns, or subtract it if the beat note occurred at more than 12 turns. Now set the dial to this new frequency, remove the trimmer plug from the top of the oscillator, and turn the adjustment until zero beat is again reached. It will be found that the high and low ends are very nearly 12 turns apart. Repeat the above procedure until such is the case; remember that a new reference point will occur at the low ends of the dial each time.

Examples of above operations:

#1

Beat note at low end of dial	= 3402 kc
Reading at which beat note should appear after 12 turns of dial	= 4002 kc
Actual dial reading	= 4003 kc
Difference frequency (4003 - 4002)	= 1 kc
Multiplied by 5	= 5 kc
Subtracted from 4003 (since beat note occurred at more than 12 turns)	= 3998 kc

After setting dial to 3998 kc and zero beating the MO to the standard with the trimmer adjustment, the low end beat note should appear at 3398 kc.

#2

Beat note on low end of dial	= 3398 kc
Reading at which dial should appear after 12 turns	= 3998 kc
Actual dial reading	= 3996 kc
Difference frequency (3998 - 3996)	= 2 kc
Multiplied by 5	= 10 kc
Added to 3996 (since beat note occurred at less than 12 turns of the dial)	= 4006 kc

After setting the dial at 4006 and zero beating the MO to the standard with the trimmer adjustment the low end beat note should appear at 3406 kc.

(11). After the oscillator has been adjusted to cover the range 3400 to 4000 kc in exactly 12 turns, the coupler set screws can be loosened and the dial set on frequency.

NOTE

The above method of adjustment is used at the factory. This is a short-cut method and proves very reliable. Actually, the object is to get the 1700 kc and the 2000 kc outputs of the oscillator exactly 12 turns apart. The objective can also be attained by using the slower method of moving the trimmer capacitor in one direction or the other; then checking results until the desired answer is obtained. Be sure to replace the trimmer cover plug after alignment.

NOTE

Somewhat greater accuracy can be obtained if the oscillator end points are set by using harmonic operation, i.e. listen in the 14 or 28 mc region for the harmonics of the 1700 and 2000 kc signals and set the corresponding harmonic of the MO to zero beat with these. Do this only after obtaining a very close adjustment as outlined above.

5.3.3. MULTIPLIER STAGES. - Should the grid drive to the final fall below 5 ma on the meter due to change of tubes or aging of components, the transmitter r-f circuits should be realigned. Proceed as outlined below only after the master oscillator has been checked and recalibrated as outlined in paragraph 5.3.2.

A small fiber screwdriver and a 1/4" open end wrench are required for these adjustments.

a. PROCEDURE.

- (1) Remove the transmitter from the cabinet and tip it up on end. (RF section up.)
- (2) Remove 3 access covers from perforated shield.
- (3) Remove the fuse from the HV primary. (This allows the low voltage supply to be turned on while the HV supply remains turned off.)
- (4) Turn the LV and HV power switches ON.
- (5) Place the CW-CAL-PH switch in the PH position.
- (6) Place the METER selector switch in the GRID position.
- (7) Adjust for maximum grid current, using the adjustments and conditions listed below in order from top to bottom of the list. (Refer to figure 5-1 for adjustment identification.)

<u>ORDER OF ADJUSTMENT</u>	<u>BAND SW SET AT</u>	<u>TUNING SET AT</u>	<u>ADJUSTMENT</u>
1	10M	28,800	3 Slugs marked "28.8"
2	40M	7,300	C150
3	40M	7,200	1 Slug marked "7.2"
4	15M	21,600	3 Trimmers marked "21.6"
5	20M	14,250	3 Trimmers marked "14.4"
6	80M	3,750 kc	1 Trimmer marked "3.6"

NOTE

In item 4 under ADJUSTMENT, the mistracking of the third multiplier plate circuit will result in low grid current when the main tuning dial is set much outside the limits of the amateur 20-meter band (14 to 14.4 mc). Proper grid current can be obtained at any frequency on the range 12.8 to 16 mc by adjustment of trimmer C139 (marked 14.4 on the third multiplier.)

NOTE

If extensive multiplier alignment has been necessary, it is likely that the two spurious signal traps will need tuning. Do not touch the spurious signal tuning condensers unless this is so, since these adjustments are very critical. C149, the spurious signal trap tuning condenser for the 80-meter band, is located on the side of the multiplier unit next to C150, see figure 5-4. These traps are tuned as follows: With the

transmitter aligned as indicated in the above paragraphs, tune the transmitter for 3.5 mc output and listen with a receiver to the 1.75 mc output. Watching the receiver "S" meter, tune C147 for minimum signal. Then tune the transmitter up on 7.15 mc and listen on 3.575 mc with the receiver. Adjust C149 for minimum signal. Both of these adjustments will be very sharp and care should be taken that they are not disturbed in the least after the adjustments have been made. Replace the multiplier bottom cover.

5.3.4. MODULATOR BIAS ADJUSTMENT. - The modulator bias can be adjusted by turning the screwdriver slot equipped potentiometer R305. For best distortion characteristics, the static, or resting, modulator plate current should be 55 ma with the 600/700 v switch in the 700 v position. Potentiometer R305 is located within the top of the cabinet near the filter capacitors; therefore the interlock switch will have to be held closed while making this adjustment. Take great care to avoid touching any components carrying high voltage.

The proper bias for the modulator grids is approximately minus 25 volts.

5.4. LUBRICATION. - The following parts should be lubricated annually or whenever the need arises by brushing a thin film of the indicated lubricant on the points of mechanical contact. Don't over-lubricate.

a. Panel Bushings: MOBILE PD535A (Socony Vacuum Oil Co.)

5.5. OSCILLATOR TUBE REMOVAL. - Replacing an oscillator tube requires the breaking of the seal around the shield and it will then become necessary to reseal the shield. If it becomes necessary to replace an oscillator tube, use a glyptal cement or a generous application of Duco cement to reseal the shield.

5.6. DESICCANT CAPSULE. - A silica-gel tube is mounted on top of the oscillator shield. The silica-gel absorbs moisture from within the oscillator and aids in retaining the oscillator calibration. Moisture causes the color of the silica-gel to change from blue to pink. The silica-gel tube is screwed into a hole in the shield. The plastic tube should be replaced by a new tube of silica-gel when all material within the tube has changed from blue to pink. New tubes of silica-gel may be ordered from the Collins Radio Company.

NOTE

The seal around the oscillator tube shield and the silica-gel tube is more easily broken if the parts are warm. This can be done safely with a light bulb or infra-red lamp placed close to the oscillator.

TYPICAL TEST VOLTAGES

DC Voltages to Ground measured with Volt-ohmyst. Conditions:
Phone - No Mod. Readings taken at LF end of each band.

TUBE	Pin	R.F.					
		3.5	7.0	14.0	21.0	27.2	28.0
V101	6AK6						
G1	1	-17.0	-16.5	-1.0	-0.9	-1.0	-0.9
K	2,7	1.0	1.0	2.9	2.85	2.85	2.9
P	5	235	230	230	225	225	225
G2	6	155	150	65	65	65	65
V102	6AG7						
K	1,3,5	2.6	2.6	3.9	3.2	3.4	3.2
G1	4	-18.	-18.	-36	-36	-38	-36
G2	6	215	215	205	205	205	210
P	8	230	230	220	220	225	225
V103	705						
P	2	235	235	215	210	215	215
G2	3						
G1	6	-24.	-23.	-56.	-21.	-69.	-51.
K	7	25.	25.	27.	27.	26.	26.
V104	705						
P	2	225	220	215	215	215	215
G2	3						
G1	6	-115	-110	-170	-175	-150	-150
K	7	-59	-56	-52	-52	-51	-50
V105	RK-4D32						
G2	2	285	300	300	300	295	295
K	4,5	0	0	0	0	0	0
G1	6	-120	-100	-93	-105	-105	-102
P	Cap	690	680	690	690	690	690

DC Voltages to Ground in Audio System (Volt-ohmyst)

4D32 Plate Current = 220 MA

Ep = 700 V

Key Down

Audio Amplifier V201, 6SL7GT				Driver V202, 6SN7GT			Modulator V203, & 4, 807		
		PH	CW			PH	CW		
Pin 1	G	-0.6	-0.8	G	0	0	G2	235	0
2	P	88	-0.9	P	235	235	G1	-25	-25
3	K	0	0	K	7.4	7.4	K	0	0
4	G	0	0	G	0	0	--	---	---
5	P	100	100	P	235	235	P	720	740
6	K	0.8	0.8	K	7.4	7.4			
7									
8									

Key up - key down conditions of V105 (4D32)
 CW operation
 f = 7 mc

	Key Up	Key Down
Plate E	820	740
Plate I	0	220
Screen E	300	300




Figure 5-2 32V-3 Parts Arrangement - Top View




Figure 5-3 32V-3 Parts Arrangement - Bottom View




Figure 5-4 32V-3 Parts Arrangement - Left Side Open




Figure 5-5 32V-3 Parts Arrangement - Right Side Open




Figure 5-6 32V-3 Parts Arrangement - Rear Open




Figure 5-7 Parts Arrangement 70E-8A - Open

SECTION 6

PARTS LIST

32V-3 TRANSMITTER

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
C101	Buffer Amp Coupling	CAPACITOR: Ceramic; 30 mmf p/m 2%; 500 WV	913 0118 00
C102	Osc. Plate Filter	CAPACITOR: Ceramic; 10,000 mmf p/m 20%; 300 WV	935 2118 00
C103	Buffer Grid Voltage	CAPACITOR: Ceramic; 30 mmf p/m 2%; 500 WV	913 0118 00
C104	Buffer Cathode By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C105	Buffer Screen By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C106	Buffer Plate By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C107	1st Mult. Coupling	CAPACITOR: Ceramic; 100 mmf p/m 10%; 500 WV	916 4003 00
C108	1st Mult. Grid By-pass	CAPACITOR: Paper; 100,000 mmf p/m 10%; 400 WV	931 3020 00
C109	1st Mult. Cathode	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C110	1st Mult. Screen	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C111	Key Click Filter	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C112	2nd Mult. Coupling	CAPACITOR: Ceramic; 100 mmf p/m 10%; 500 WV	916 4003 00
C113	1st Mult. Plate By-pass	CAPACITOR: Mica; 650 mmf p/m 2%; 500 WV	935 5061 00
C114	1st Mult. Plate Tuning	CAPACITOR: Mica; 22 mmf p/m 5%; 500 WV	935 0077 00
C115	1st Mult. Plate Tuning	CAPACITOR: Mica; 22 mmf p/m 10%; 500 WV	935 0078 00
C116	1st Mult. Tuning	CAPACITOR: Ceramic 8-50 mmf; 350 WV	917 1038 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER	ITR
C117	1st Mult Plate Tuning	CAPACITOR: Mica; 180 mmf p/m 5%; 500 WV	935 0116 00	C11
C118	1st Mult Plate Tuning	CAPACITOR: Ceramic 8-50 mmf; 350 WV	917 1038 00	C11
C119	2nd Mult Screen By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C120	2nd Mult Screen By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C121	2nd Mult Plate By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C122	3rd Mult Coupling	CAPACITOR: Ceramic; 100 mf p/m 10%; 500 WV	916 4003 00	C11
C123	2nd Mult Plate Tuning	CAPACITOR: Mica; 20 mmf p/m 5%; 500 WV	935 0076 00	C11
C124	2nd Mult Plate Tuning	CAPACITOR: Mica; 22 mmf p/m 10%; 500 WV	935 0078 00	C11
C125	2nd Mult Plate Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00	C11
C126	2nd Mult Plate Tuning	CAPACITOR: Mica; 150 mmf p/m 2%; 500 WV	935 0184 00	C11
C127	2nd Mult Plate Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00	C11
C128	3rd Mult Cathode By-Pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C129	3rd Mult Screen By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C130	3rd Mult Screen By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C131	3rd Mult Plate By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C132	3rd Mult Plate By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11
C133	2nd Mult Cathode By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00	C11

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
C134	3rd Mult Plate Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C135		CAPACITOR: Not Used	
C136	3rd Mult Plate Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C137	3rd Mult Plate Tuning	CAPACITOR: Mica; 120 mmf p/m 5%; 500 WV	935 0109 00
C138		CAPACITOR: Not Used	
C139	3rd Mult Plate Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C140	PA Coupling	CAPACITOR: Ceramic; 100 mmf p/m 10%; 500 WV	916 4003 00
C141	PA Grid By-pass	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C142	PA Screen By-pass	CAPACITOR: Mica; 1000 mmf p/m 20%; 2500 WV	936 0250 00
C143		CAPACITOR: Not Used	
C144	PA Filament By-pass	CAPACITOR: Mica; 500 mmf p/m 20%; 500 WV	912 0302 00
C145	3rd Mult Plate Blocking	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C146	3rd Mult Plate Tuning	CAPACITOR: Mica; 20 mmf p/m 5%; 500 WV	935 0076 00
C147	160 Meter Tap Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C148	80 Meter Tap fixed Tuning	CAPACITOR: Mica; 120 mmf p/m 5%; 500 WV	935 0109 00
C149	80 Meter Tap Var. Tuning	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C150	L-108 Trimmer	CAPACITOR: Ceramic; 8-50 mmf; 350 WV	917 1038 00
C151	Key Filter	CAPACITOR: Ceramic; 100 mmf p/m 10%; 500 WV	916 4003 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
C201	Audio Input RF filter	CAPACITOR: Mica; 47 mmf p/m 20%; 500 WV	935 0093 00
C202	Audio Coupling	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C203	V201 Plate By-pass	CAPACITOR: Paper; 2 mf p/m 10%; 600 WV	930 0046 00
C204	V201 Plate By-pass	CAPACITOR: Paper, 2 mf p/m 10%; 600 WV	930 0046 00
C205	Driver Grid Coupling	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C206	Driver Cathode By-pass	CAPACITOR: Paper; 2 mf p/m 10%; 600 WV	930 0046 00
C207	Mod Cathode By-pass	CAPACITOR: Paper; 2 mmf p/m 10%; 600 WV	930 0046 00
C208		CAPACITOR: Not Used	
C209		CAPACITOR: Ceramic; 100 mmf p/m 10%; 500 WV	916 4003 00
C210		CAPACITOR: Not Used	
C211	Audio Plate Decoupling	CAPACITOR: Paper; .5 mf p/m 20%; 600 WV	956 2086 40
C212		CAPACITOR: Not Used	
C213		CAPACITOR: Not Used	
C214		CAPACITOR: Not Used	
C215		CAPACITOR: Not Used	
C216	Microphone Coupling	CAPACITOR: Mica; 10,000 mmf p/m 10%; 300 WV	935 2117 00
C217	LV Rect Filter	CAPACITOR: Electrolytic; 10 mf plus 50% minus 10%; 350 WV	183 1048 00
C218		CAPACITOR: Not Used	
C301	LV Rect Filter	CAPACITOR: Paper; 4 mf plus 40 minus 15%; 600 WV	961 3005 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
C302	LV Rect Filter	CAPACITOR: Paper; 4 mf plus 40 minus 15%; 600 WV	961 3005 00
C303	HV Rect Filter	CAPACITOR: Paper; 8 mf p/m 20%; 1000 WV	930 0150 00
C304		CAPACITOR: Not Used	
C305	HV Filter Tuning	CAPACITOR: Paper; .25 mf p/m 10%; 2000 WV	930 7220 00
C306	Plate Meter By-pass	CAPACITOR: Mica; 150 mmf p/m 20%; 2500 WV	936 0195 00
C307	Noise Suppressor	CAPACITOR: Paper; 0.1 mf plus 20% minus 10%; 600 WV	241 0006 00
C308	Noise Suppressor	CAPACITOR: Paper; 0.1 mf plus 20% minus 10%; 600 WV	241 0006 00
C309	Noise Suppressor	CAPACITOR: Paper; 0.1 mf plus 20% minus 10%; 600 WV	241 0006 00
C310	Noise Suppressor	CAPACITOR: Paper; 0.1 mf plus 20% minus 10%; 600 WV	241 0006 00
C311	Noise Suppressor	CAPACITOR: Paper; 0.1 mf plus 20% minus 10% 600 WV	241 0006 00
C312	Bias Filter	CAPACITOR: Electrolytic; 20 mf 150 WV minus 10% plus 100%	183 1042 00
C313	Plate Meter By-pass	CAPACITOR: Mica; 150 mmf p/m 20%; 2500 WV	936 0195 00
C314	Meter By-pass	CAPACITOR: Mica; 150 mmf p/m 20% 2500 WV	936 0195 00
C315	Meter By-pass	CAPACITOR: Mica; 150 mmf p/m 20%; 2500 WV	936 0195 00
C401	PA Plate Blocking	CAPACITOR: Mica; 1000 mmf p/m 20%; 2500 WV	936 0250 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
C402	PA Plate By-pass	CAPACITOR: Mica; 2200 mmf p/m 20%; 2500 WV	936 1083 00
C403	Final Tuning	CAPACITOR: Variable Air Dielectric; Dual Sect; 10-150 mmf per sect	920 0011 00
C403A	Part of C403	CAPACITOR: Section of C403	
C403B	Part of C403	CAPACITOR: Section of C403	
C404	Final Tuning	CAPACITOR: Ceramic; 50 mmf p/m 10%; WV; 2500 v rms at 2 mc 1000 v rms at 16 mc	913 4503 20
C405	Antenna Loading	CAPACITOR: Variable air-dielectric single sect; 15-300 mmf	920 0014 00
C406	Antenna Loading	CAPACITOR: Mica; 470 mmf p/m 10%; 2500 WV	936 0226 00
C407	Antenna Loading	CAPACITOR: Mica; 470 mmf p/m 5%; 2500 WV	936 0226 00
C408	Antenna Loading	CAPACITOR: Mica; 910 mmf p/m 10%; 2500 WV	936 0246 00
C409	Final Tuning	CAPACITOR: Ceramic; 50 mmf p/m 10%; WV; 2500 v rms at 2 mc 1000 v rms at 16 mc	913 4503 20
C410	Antenna Loading	CAPACITOR: Mica; 910 mmf p/m 10%; 2500 WV	936 0246 00
C411	Antenna Loading	CAPACITOR: Mica; 470 mmf p/m 10%; 2500 WV	936 0226 00
C412	Antenna Loading	CAPACITOR: Mica; 470 mmf p/m 10%; 2500 WV	936 0226 00
C413	Trap Tuning	CAPACITOR: Ceramic; 67 mmf p/m 5%; 5000 WV; p/o E-401	913 0090 00
E304	Wire Tie Point	TERMINAL: Ceramic bushing 13/32" diam x 5/16" thk w/ solder lug 17/32" lg	190 1103 00
E305	Wire Tie Point	TERMINAL: Ceramic bushing 13/32" diam x 5/16" thk w/ solder lug 17/32" lg	190 1103 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
E306	Wire Tie Point	TERMINAL: Ceramic bushing 13/32" diam x 5/16" thk w/ solder lug 17/32" lg	190 1103 00
E307	Wire Tie Point	TERMINAL: Ceramic bushing 13/32" diam x 5/16" thk w/ solder lug 17/32" lg	190 1103 00
E308	Rear Terminal Strip	CONNECTOR: 14 term, barrier type strip w/ lugs on back	367 0022 00
E309	Ground Connector	POST, BINDING: Push type; 1/8" wire hole	372 1400 00
E401	Parasitic Suppressor	PA TRAP ASSEM: 1-1/3 turns tinned #14 wire, 100 ohm low resistor, 67 mmf capacitor (incl C413, L405)	505 4443 002
F301	LV and Filament	FUSE: 3 amp; 250 v	264 4080 00
F302	High Voltage	FUSE: 5 amp; 250 v	264 4090 00
I301	Pilot Lamp	BULB: Pilot light; 110 v, 55 ma; 6 w; candelabra base; T4-1/2 bulb	262 3330 00
I302	Pilot Lamp	BULB: Pilot light; 110 v, 55 ma; 6 W; candelabra base; T4-1/2 bulb	262 3330 00
	For I302	JEWEL: Pilot light red faceted	262 2110 00
I303	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base; T1-3/4 bulb	262 0023 00
I304	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base; T1-3/4 bulb	262 0023 00
I305	Dial Lamp	BULB: Pilot light; 6 v, .2 amp midget fl base; T1-3/4 bulb	262 0023 00
I306	Dial Lamp	BULB: Pilot light; 6 v, .2 amp midget fl base; T1-3/4 bulb	262 0023 00
I307	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget flange base; T1-3/4 bulb	262 0023 00
I308	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget flange base; T1-3/4 bulb	262 0023 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
I309	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base; T1-3/4 bulb	262 0023 00
I310	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base; T1-3/4 bulb	262 0023 00
I311	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base, T1-3/4 bulb	262 0023 00
I312	Dial Lamp	BULB: Pilot light; 6 v, .2 amp; midget fl base; T1-3/4 bulb	262 0023 00
J101	Key	JACK: Phone single circuit, midget	360 0008 00
J102	Cable	CONNECTOR: Std octal socket	220 1850 00
J201	Microphone	CONNECTOR: 2 female cont; wall mtg	369 1004 00
J202	Modulator	CONNECTOR: Std octal socket	220 1850 00
J301	Antenna Connector	CONNECTOR: Single round female cont	357 9003 00
K301	Carrier Control	RELAY: Circuit control; cont 1A1B1A and 2A; 48 v coil	970 1014 00
L101	Osc plate choke	COIL: RF choke; 4 pi; duo-log wnd; 2.5 mh p/m 20%; .125 amp	240 2100 00
L102		COIL: Not Used	
L103	Buffer Plate Choke	COIL: RF choke; 500 uh p/m 10%; 4 pi; universal wnd	240 0042 00
L104	1st Mult Tuning	COIL: LF; 38T #28 wire	503 2896 002
L105	2nd Mult Tuning	COIL: MF; 17.3T #28 wire	503 2895 002
L106	2nd Mult Plate Choke	COIL: RF choke; 2 pi; duo-lat wnd; 208 uh	240 6000 00
L107	3rd Mult Tuning	COIL: HF 7.6 T #28 wire	503 2835 001
L108	3rd Mult Tuning	COIL: LF; 38T #28 wire	503 2896 002

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
L109	PA Grid Choke	COIL: RF choke; 4 pi; duo-lat wnd; 2.5 mh p/m 20%; .125 amp	240 2100 00
L110	3rd Mult Tuning	COIL: 23T #26 Wire	503 4512 001
L111	1st Mult Plate Choke	COIL: RF choke; 3 pi; universal wnd; 1 mh plus 20 minus 10%	240 0047 00
L112	3rd Mult Plate Choke	COIL: RF choke; 3 pi; universal wnd; 1 mh plus 20 minus 10%	240 0047 00
L113	Key Filter	COIL: RF choke; 2.7 mh, 300 ma; 45 turns #30 AWG wire	240 0012 00
L201		COIL: Not used	
L202		COIL: Not used	
L203		COIL: Not used	
L204		COIL: Not used	
L205	Modulator Plate Choke	COIL: RF choke; 500 uh p/m 10%; 4 pi, universal wnd	240 0042 00
L206	Modulator Plate Choke	COIL: RF choke; 500 uh p/m 10%; 4 pi, universal wnd	240 0042 00
L207	PTT Line Filter	COIL: RF choke; 2.7 mh, 300 ma, 45 turns #30 AWG wire	240 0012 00
L301	LV Filter	REACTOR, FILTER: 11 hy p/m 15%	668 0012 00
L302	LV Filter	REACTOR, FILTER: 11 hy p/m 15%	668 0012 00
L303	HV Filter	REACTOR, FILTER: 5 hy p/m 15%	668 0055 00
L304	PA Meter Filter Choke	COIL: RF choke; 2.7 mh, 300 ma, 45 turns #30 AWG wire	240 0012 00
L305	PA Meter Filter Choke	COIL: RF choke; 2.7 mh, 300 ma, 45 turns #30 AWG wire	240 0012 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
L306	Meter Filter Choke	COIL: RF choke; 2.7 mh, 300 ma, 45 turns #30 AWG wire	240 0012 00
L307	Meter Filter Choke	COIL: RF choke; 2.7 mh, 300 ma, 45 turns #30 AWG wire	240 0012 00
L401	PA Plate Tuning	COIL: LF tank; 20T #14 wire	503 2892 002
L402	PA Plate Tuning (28 mc)	COIL: HF tank; 5T silver pl copper tubing	503 2831 001
L403	PA Plate Choke	COIL: RF choke; 169 turns of #27 chrome oxide wire	504 3667 003
L404	Network Coil	COIL: output; 32 turns; #18 wire	503 6486 001
L405	Trap Tuning	COIL: PA Trap Assem (E401)	505 4452 002
M301	Mult Purpose	METER: 0-5 ma DC; 50 scale divisions; marked 0250, 0500, 0100	458 0110 00
M302	PA Plate	METER: 0500 ma DC; 50 scale divisions	450 1500 00
P101	Osc. Power	CONNECTOR: 4 prong plug; part of oscillator filter assem	503 2868 002
P201	Microphone	CONNECTOR: 2 prong plug	369 1005 00
P301	Modulator power	CONNECTOR: Std 8 term octal plug	369 1009 00
P302	RF circuits power	CONNECTOR: Std 8 term octal plug	369 1009 00
P303		CONNECTOR: Not Used	
P304	Antenna Plug	CONNECTOR: Single round male contact	357 9040 00
R101		RESISTOR: Not Used	
R102	Buffer Grid	RESISTOR: 22,000 ohm p/m 10%; 1/2 w	745 1142 00
R103	Buffer Cathode	RESISTOR: 560 ohm p/m 10%; 1/2 w	745 1076 00
R104	Buffer Screen	RESISTOR: .33 meg p/m 10%; 1/2 w	745 1191 00
R105	V101, V102, V103 grid	RESISTOR: .10 meg p/m 10%; 1/2 w	745 1170 00
R106	1st Mult Grid	RESISTOR: .10 meg p/m 10%; 1/2 w	745 1170 00
R107	1st Mult Cathode	RESISTOR: 820 ohm p/m 10%; 1/2 w	745 1083 00
R108	1st Mult Screen	RESISTOR: 22,000 ohm p/m 10%; 1/2 w	745 1142 00
R109	1st Mult Plate Decoupling	RESISTOR: 1000 ohm p/m 10%, 1 w	745 3086 00
R110	2nd Mult Grid	RESISTOR: .10 meg p/m 10%; 1/2 w	745 1170 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
R111	2nd Mult Screen	RESISTOR: 10,000 ohm p/m 10%; 1/2 w	745 1128 00
R112	2nd Mult Plate Decoupling	RESISTOR: 1000 ohm p/m 10%; 1 w	745 3086 00
R113	3rd Mult Grid	RESISTOR: .10 meg p/m 10%; 1/2 w	745 1170 00
R114	3rd Mult Screen	RESISTOR: 10,000 ohm p/m 10%; 1/2 w	745 1128 00
R115	3rd Mult Plate Decoupling	RESISTOR: 470 ohm p/m 10%; 1 w	745 3072 00
R116	3rd Mult Plate Decoupling	RESISTOR: 470 ohm p/m 10%; 1 w	745 3072 00
R117	3rd Mult Grid Stabilizer	RESISTOR: 10 ohm p/m 10%; 1/2 w	745 1002 00
R118	2nd Mult Cathode	RESISTOR: 1500 ohm p/m 10%; 1/2 w	745 1093 00
R119	PA Grid Meter Shunt	RESISTOR: 6.2 ohm p/m 5%; 1/2 w	707 0104 00
R120	PA Grid	RESISTOR: 3300 ohm p/m 10%; 1 w	745 3107 00
R121	3rd Mult Grid Voltage Divider	RESISTOR: .22 meg p/m 10%; 1/2 w	745 1184 00
R122	3rd Mult Grid Return	RESISTOR: 680 ohm p/m 10%; 2 w	745 5079 00
R123	PA Screen Stabilizer	RESISTOR: 47 ohm p/m 10%; 1 w	745 3030 00
R124		Not Used	
R125	Dial Light Dropping	RESISTOR: 2 ohm p/m 10%; 2 w	710 1070 00
R126	Voltage Regulator Dropping	RESISTOR: 5600 ohm p/m 10%; 2 w	745 5118 00
R127	Voltage Regulator Dropping	RESISTOR: 5600 ohm p/m 10%; 2 w	745 5118 00
R128	V-10 ⁴ plate dropping	RESISTOR: 4700 ohm p/m 10%; 2 w	745 5114 00
R129	V-10 ⁴ plate dropping	RESISTOR: 4700 ohm p/m 10%; 2 w	745 5114 00
R203		RESISTOR: Not Used	
R204	V201 Cathode	RESISTOR: 4700 ohm p/m 10%; 1/2 w	745 1114 00
R205	Audio Gain Control	RESISTOR: .5 meg p/m 20%; 1/2 w	376 3027 00
R206	V201 Plate	RESISTOR: .47 megohm p/m 10%; 1/2 w	745 1198 00
R207	V201 Plate	RESISTOR: .47 megohm p/m 10%; 1/2 w	745 1198 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
R208	V201 Plate Decoupling	RESISTOR: 47,000 ohm p/m 10%; 1/2 w	745 1156 00
R209	V201 Plate Decoupling	RESISTOR: 47,000 ohm p/m 10%; 1/2 w	745 1156 00
R210	V202 Grid	RESISTOR: .47 megohm p/m 10%; 1/2 w	745 1198 00
R211	V202 Cathode	RESISTOR: 560 ohm p/m 10%; 1/2 w	745 1076 00
R212	thru R215	RESISTOR: Not Used	
R216	Audio Decoupling	RESISTOR: 2200 ohm p/m 10%; 1 w	745 3100 00
R301	V105 Screen Dropping	RESISTOR: 12,000 ohm p/m 5%; 25 w	710 0366 00
R302		RESISTOR: Not Used	
R303		RESISTOR: Not Used	
R304	V105 Screen Bleeder	RESISTOR: 25,000 ohm p/m 10%; 25 w size	710 3254 20
R305	Mod Bias Control	RESISTOR: Variable; WW; 1000 ohm p/m 10%; 4 w	377 0007 00
R306	Bias Bleeder	RESISTOR: 750 ohm p/m 5%; 10 w	710 1750 10
R307	LV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00
R308	LV Meter Shunt	RESISTOR: 25 ohm p/m 5%; 1/2 w	701 0001 00
R309	Relay Voltage Divider	RESISTOR: 5000 ohm p/m 10%; 10 w	710 1542 00
R310	Relay Voltage Divider	RESISTOR: 7500 ohm p/m 10%; 10 w	710 0033 00
R311	LV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00
R312	HV Meter Shunt	RESISTOR: 25 ohm p/m 5%; 1/2 w	701 0001 00
R313	HV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00
R314	HV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00
R315	Mod. Shunt Motor	RESISTOR: WW; 51 ohm p/m 5%; 1/2 w	707 0026 00
R316	HV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00
R317	HV Bleeder	RESISTOR: 0.10 megohm p/m 5%; 2 w	745 5169 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
R318	Mod. Ind Shunt	RESISTOR: 25 ohm p/m 5%; 1/2 w	701 0001 00
R319	Voltage Regulator Dropping	RESISTOR: 2000 ohm p/m 10%; 10 w	710 1242 00
R320	Series Tuning	RESISTOR: WW; 15 ohm p/m 10%; .25 w	710 3152 00
R321	Series Tuning	RESISTOR: WW; 15 ohm p/m 10%; .25 w	710 3152 00
S101	Band Change Switch	SWITCH: 8 pole, 5 position, 4 sect; non- shorting	503 2923 004
S101A		SWITCH: Part of S101	
S101B		SWITCH: Part of S101	
S101C		SWITCH: Part of S101	
S101D		SWITCH: Part of S101	
S101E		SWITCH: Part of S101	
S101F		SWITCH: Part of S101	
S101G		SWITCH: Part of S101	
S101H		SWITCH: Part of S101	
S301	Cabinet Interlock	SWITCH: SP normally open	260 0526 00
S302	Emission Selector	SWITCH: Band change; 8 pole; 3 position 3 sect; non-shorting	259 0044 00
S302A		SWITCH: Part of S302	
S302B		SWITCH: Part of S302	
S302C		SWITCH: Part of S302	
S302D		SWITCH: Part of S302	
S302E		SWITCH: Part of S-302	
S302F		SWITCH: Not Used	

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
S302G		SWITCH: Not Used	
S302H		SWITCH: Not Used	
S303	High Voltage Switch	SWITCH: SPST toggle; 25 amp	266 1040 00
S304	Low Voltage Switch	SWITCH: SPST toggle; 25 amp	266 1040 00
S305	600-700 v selector	SWITCH: DPDT toggle; 1 amp 250 v, 3 amp 125 v	260 0551 00
S306	Meter Selector	SWITCH: Band change; 2 pole, 5 position, 1 sect; non-shorting	259 0045 00
S306A		SWITCH: Part of S306	
S306B		SWITCH: Part of S306	
S307		SWITCH: SPST toggle; 3 amp 250 v	260 0857 00
S401	PA Plate Circuit	SWITCH: Band change; 2 pole, 5 position, 1 sect; shorting	259 0043 00
S401A		SWITCH: Part of S401	
S401B		SWITCH: Part of S401	
S402	Antenna Loading	SWITCH: Band change; 6 position, shorting type	269 1248 00
T201	Modulator input	TRANSFORMER: Driver; pri; 12,000 ohm, secd; 5300 ohm CT, freq response 300- 3500 cps p/m 3 db	667 0011 00
T202	Modulation	TRANSFORMER: Mod; pri; 7000 ohm CT, 100 ma DC max, bal; secd; 500/3750 ohm, 200 ma DC, unbalanced; freq response 300/3500 cps p/m 3 db; 60 w	667 0010 00
T301	Low Voltage	TRANSFORMER: pri; 115 v, secd #1; 850 v CT, secd #2; 5 v, 4 amp, secd #3; 5 v, 4 amp, secd #4; 6.3 v, 9 amp 50/60 cps	662 0009 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
T302	High Voltage	TRANSFORMER: Power; 50/60 cps; pri; 115 v, secd; 1100 v CT, w/ pri leads #1 and #2 on 115 v, secd leads #4 and #6 should be 1370 v rms	662 0014 00
V101	Buffer Amp.	TUBE: Type 6AK6; power amp pentode; miniature	257 0041 00
V102	1st Multiplier	TUBE: Type 6AG7; video power amp pentode	255 0039 00
V103	2nd Multiplier	TUBE: Type 7C5; beam power amp; octalox	255 0141 00
V104	3rd Multiplier	TUBE: Type 7C5; beam power amp; octalox	255 0141 00
V105	Power Amplifier	TUBE: Type RK 4D32; tetrode	266 0078 00
V106	Oscillator Voltage Regulator	TUBE: OA2 voltage regulator	257 0052 00
V107	Oscillator Voltage Regulator	TUBE: OB2 voltage regulator	257 0058 00
V201	1st and 2nd Audio	TUBE: Type 6SL7GT; twin triode amp	255 0040 00
V202	Audio Driver	TUBE: Type 6SN7GT; twin triode amp	255 0033 00
V203	Modulator	TUBE: Type 807, transmitting beam power amp	255 0033 00
V204	Modulator	TUBE: Type 807, transmitting beam power amp	255 0033 00
V301	Low Voltage Rectifier	TUBE: Type 5Z4; full wave hi-vac rect	255 0084 00
V302	High Voltage Rectifier	TUBE: Type 5R4GY; full-wave hi-vac rect	257 0020 00
V303	High Voltage Rectifier	TUBE: Type 5R4GY; full-wave hi-vac rect	257 0020 00
V304	Bias Voltage Regulator	TUBE: Type OA3/VR-75; voltage regulator	257 0008 00
V305	Screen Voltage Limiter	TUBE: Type OA2; voltage limiter	257 0052 00
V306	Screen Voltage Limiter	TUBE: Type OA2; voltage limiter	257 0052 00

ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER	
XF301	Holder for F301	HOLDER, FUSE: Extractor post for 1/4" x 1-1/4" fuses	265 1002 00	X
XF302	Holder for F302	HOLDER, FUSES: Extractor post for 1/4" x 1-1/4" fuses	265 1002 00	X
XI301	Mtg for I301	MTG, PILOT LIGHT: Bracket for candelabra base bulb	262 1320 00	X
XI302	Mtg for I302	MTG, PILOT LIGHT: Bracket for candelabra base bulb	262 1320 00	
XV101	Socket for V101	SOCKET, TUBE: Miniature shielded	220 1003 00	
XV102	Socket for V102	SOCKET, TUBE: Octal, bakelite	220 1850 00	
XV103	Socket for V103	SOCKET, TUBE: Loctal, bakelite	220 1002 00	
XV104	Socket for V104	SOCKET, TUBE: Loctal, bakelite	220 1002 00	
XV105	Socket for V105	SOCKET, TUBE: 7 prong ceramic w/ clips	220 1072 00	
XV106	Socket for V106	SOCKET, TUBE: Miniature shielded	220 1003 00	
XV107	Socket for V107	SOCKET, TUBE: Miniature shielded	220 1003 00	
XV201	Socket for V201	SOCKET, TUBE: Octal, bakelite	220 1850 00	
XV202	Socket for V202	SOCKET, TUBE: Octal, bakelite	220 1850 00	
XV203	Socket for V203	SOCKET, TUBE: 5 prong ceramic w/ clips	220 5520 00	
XV204	Socket for V204	SOCKET, TUBE: 5 prong ceramic w/ clips	220 5520 00	
XV301	Socket for V301	SOCKET, TUBE: Octal, bakelite	220 1850 00	
XV302	Socket for V302	SOCKET, TUBE: Octal ceramic w/ clips and key way	220 5810 00	
XV303	Socket for V303	SOCKET, TUBE: Octal ceramic w/ clips and key way	220 5810 00	


ITEM	CIRCUIT FUNCTION	DESCRIPTION	COLLINS PART NUMBER
XV304	Socket for V304	SOCKET, TUBE: Octal, bakelite	220 1850 00
XV305	Socket for V305	SOCKET, TUBE: Miniature, 7 term	220 1003 00
XV306	Socket for V306	SOCKET, TUBE: Miniature, 7 term	220 1003 00

ANTENNAS
WITH
52 OHM COAXIAL FEED LINES




Published By
Collins Radio Company
Cedar Rapids, Iowa

520 9722 00
15 March 1952
Second Edition



THIS SYSTEM PERMITS USE OF A BALANCED OPEN WIRE LINE TO REDUCE LOSSES ON LONG TRANSMISSION LINES. CONSTRUCTION DETAILS OF THE UNBALANCED TO BALANCED IMPEDANCE MATCHING TRANSFORMER (BALUN) USED BETWEEN THE OPEN WIRE LINE AND THE 52 OHM RG-8/U COAXIAL CABLE ARE SHOWN BELOW.





NOTES:


- | FREQ. MC. | OPEN WIRE LINE IMPEDENCE | LENGTH - INCHES | | |
|------------|--------------------------|-----------------|--------|--------|
| | | A | B | C |
| 27 TO 29.7 | 300 OHMS | 15 3/8 | 38 1/4 | 69 5/8 |
| 27 TO 29.7 | 523 OHMS | 10 5/8 | 44 1/2 | 69 5/8 |
| 14 TO 14.3 | 523 OHMS | 21 1/4 | 92 1/4 | 139 |

DIMENSIONS D, E, AND F ARE NOT CRITICAL AND MAY BE ADAPTED TO THE INDIVIDUAL INSTALLATION. DIMENSION D SHOULD BE LONG ENOUGH TO PERMIT SILVER SOLDERING BRASS PLATE AND TUBES TOGETHER. DIMENSION E SHOULD BE LONG ENOUGH TO PERMIT ADJUSTMENT OF THE SHORTING BAR. DIMENSION F SHOULD BE LONG ENOUGH TO PROVIDE SUFFICIENT OVERHANG FOR CONNECTING THE RG-11/U CABLE.
- BRASS PLATE OF CONVENIENT SIZE SILVER SOLDERED TO THE TWO BRASS TUBES. PLATE MAY BE GROUNDED OR UNGROUNDED AND IS DESIGNED TO SECURE THE BALUN TO AN END SUPPORT.
- ATTACH A COAX CONNECTOR HERE TO PERMIT ATTACHING A LENGTH OF 52 OHM RG-8/U COAX.
- REMOVE OUTER JACKET AND SHIELD FROM A LENGTH OF RG-11/U 75 OHM COAXIAL CABLE. CUT THE OUTER JACKET 1/2 INCH SHORTER THAN THE SHIELD. BEVEL THE OUTER EDGE OF THE 3/8" O.D. BRASS TUBE. SLIDE THE DIELECTRIC INSIDE THE TUBE. FORCE THE BEVELED END OF THE BRASS TUBE BETWEEN THE DIELECTRIC AND THE SHIELD FOR A DISTANCE OF ABOUT 2 INCHES AS SHOWN. SOLDER THE SHIELD TO THE TUBE, USING A MINIMUM AMOUNT OF HEAT TO AVOID DAMAGING THE DIELECTRIC. COVER THE AREA WITH SCOTCH ELECTRICAL TAPE TO EXCLUDE MOISTURE.
- THIS SHORTING BAR SHOULD BE MOVABLE TO PERMIT ADJUSTING THE BALUN TO REDUCE THE OVERALL STANDING WAVE RATIO OF THE SYSTEM.
- REMOVE THE OUTER JACKET AND SHIELD FROM A LENGTH OF RG-8/U 52 OHM COAX. INSERT THE PROPER LENGTH OF BARE DIELECTRIC INSIDE THE TUBE.
- SOLDER INNER CONDUCTORS TOGETHER. COVER THE TUBE ENDS AND ALL OF THE CABLE BETWEEN WITH A CONTINUOUS WRAPPING OF SCOTCH ELECTRICAL TAPE TO EXCLUDE MOISTURE.
- INSTALL A BRACKET FOR ATTACHING THE OPEN WIRE LINE. IF BRACKET IS SOLDERED, BE VERY CAREFUL TO AVOID OVERHEATING AND DAMAGING THE DIELECTRIC.

BALUN WITH BALANCED OPEN WIRE LINE
FOR REDUCTION OF LOSSES ON LONG TRANSMISSION LINES.



20 METER BEAM WITH SHORTENED UNBALANCED TO BALANCED TRANSFORMER (BALUN) FEED SYSTEM. GENERAL CONSTRUCTION IS THE SAME AS THE TEN METER BEAM.



FOR DETAIL SEE FIGURE A
 PHENOLIC BLOCK 2" X 1 1/2" X 1/2" WRAP CABLES
 AND BLOCK WITH SCOTCH ELECTRICAL TAPE
 SPACE BLOCKS 6 FEET APART ALONG BALUN.

FIGURE A

CUT OFF SHIELD AND OUTER JACKET AS SHOWN. ALLOW DIELECTRIC TO EXTEND PART WAY TO OTHER CABLE. COVER ALL EXPOSED SHIELD AND DIELECTRIC ON BOTH CABLES WITH A CONTINUOUS WRAPPING OF SCOTCH ELECTRICAL TAPE TO EXCLUDE MOISTURE.

KEEP BALUN AT LEAST 6 INCHES CLEAR OF GROUND AND OTHER OBJECTS.

DIMENSIONS SHOWN HERE ARE FOR THE 40 METER BAND. THIS ANTENNA MAY BE BUILT FOR OTHER BANDS BY USING DIMENSIONS THAT ARE MULTIPLES OR SUBMULTIPLES OF THE DIMENSIONS SHOWN. BALUN SPACING IS 1 1/2 INCHES ON ALL BANDS.

FIGURE B

REMOVE OUTER JACKET FROM A SHORT LENGTH OF CABLE AS SHOWN HERE. UNBRAID THE SHIELD OF COAX C, CUT OFF THE DIELECTRIC AND INNER CONDUCTOR FLUSH WITH THE OUTER JACKET. DO NOT CUT THE SHIELD. WRAP SHIELD OF COAX C AROUND SHIELD OF COAX D. SOLDER THE CONNECTION, BEING VERY CAREFUL NOT TO DAMAGE THE DIELECTRIC MATERIAL. HOLD CABLE D STRAIGHT WHILE SOLDERING. COVER THE AREA WITH A CONTINUOUS WRAPPING OF SCOTCH ELECTRICAL TAPE. NO CONNECTION TO INNER CONDUCTORS.

FOR DETAIL SEE FIGURE B

HALF WAVE ANTENNA WITH QUARTER WAVE UNBALANCED TO BALANCED TRANSFORMER (BALUN) FEED SYSTEM





FIGURE A.

CUT OFF SHIELD AND OUTER JACKET AS SHOWN. ALLOW DIELECTRIC TO EXTEND PART WAY TO OTHER CABLE. COVER ALL EXPOSED DIELECTRIC ON BOTH CABLES WITH A CONTINUOUS WRAPPING OF SCOTCH ELECTRICAL TAPE TO EXCLUDE MOISTURE

KEEP BALUN AT LEAST 6 INCHES CLEAR OF GROUND AND OTHER OBJECTS

DIMENSIONS SHOWN HERE ARE FOR THE 80 METER BAND. THIS ANTENNA MAY BE BUILT FOR OTHER BANDS BY USING DIMENSIONS THAT ARE MULTIPLES OR SUBMULTIPLES OF THE DIMENSIONS SHOWN. BALUN SPACING IS 1 1/2 INCHES ON ALL BANDS.





FIGURE B.

REMOVE OUTER JACKET FROM A SHORT LENGTH OF CABLE AS SHOWN HERE. UNBRAID THE SHIELD OF COAX C. CUT OFF THE DIELECTRIC AND INNER CONDUCTOR FLUSH WITH THE OUTER JACKET. DO NOT CUT THE SHIELD. WRAP SHIELD OF COAX C AROUND SHIELD OF COAX D. SOLDER THE CONNECTION, BEING VERY CAREFUL NOT TO DAMAGE THE DIELECTRIC MATERIAL. HOLD CABLE D STRAIGHT WHILE SOLDERING. COVER THE AREA WITH A CONTINUOUS WRAPPING OF SCOTCH ELECTRICAL TAPE. NO CONNECTION TO INNER CONDUCTORS.

FOR DETAIL SEE FIGURE B



BROADBAND ANTENNA WITH QUARTER WAVE UNBALANCED TO BALANCED TRANSFORMER (BALUN) FEED SYSTEM.

COLLINS RADIO COMPANY

MAIN PLANT:

855 35TH ST. N.E., CEDAR RAPIDS, IOWA

BRANCHES:

1937 IRVING BOULEVARD, DALLAS, TEXAS

11 WEST 42ND STREET, NEW YORK 18, N. Y.

2700 WEST OLIVE AVE., BURBANK, CALIF.

